


## AIR VALVE REBUILD KIT No. A-29488 FOR DOUBLE DIAPHRAGM PUMP



### INSTRUCTIONS FOR VALVE REBUILDING:

1. When disassembling valve, lay components out in an orderly fashion to insure correct re-assembly.
2. Lightly grease the seals before assembling valve.
3. This valve has (2) different diameter pilot pistons. With the pump upright and the manifold block facing assembler, the end cap with the smaller piston (marked DP) must be on the left.

### NOTE

This Rebuild Kit is intended for use with a number of different valves.  
**SOME PARTS MAY NOT BE USED.**